

## Ignitor™ COMMON QUESTIONS AND ANSWERS

**Q. What is the first thing I should check if the engine would not start?**  
A. Make certain all wires are connected securely to the proper terminals.

**Q. The engine will not start or runs rough. Are there any tests I can do?**  
A. Yes, remove the red Ignitor™ wire from the coil. Connect a jumper wire from the positive side of the battery to the red Ignitor™ wire just removed from the coil. If the engine starts you have a low voltage problem (This is a very common problem). Remember this is just a test. **Not intended for permanent installation.**

**Q. How can I fix a low voltage problem?**

A. First, if you have an external ballast resistor, connect the red Ignitor™ wire to the ignition wire prior to the ballast resistor. Second, if you do not have a ballast resistor you must connect the red Ignitor™ wire to a 12-volt source that is controlled by the ignition switch.

**Q. What type of coil do I need?**

A. The Ignitor™ is compatible only with a "points style" coil. Six & eight cylinder engines require a minimum of 1.5 ohms of resistance. Four cylinder engines require a minimum of 3.0 ohms of resistance.

**Q. How do I check my coil for resistance?**

A. First you need an ohmmeter. Remove all the wires from the coil. Attach the meter to both the positive and negative terminals. The reading must be 1.5 ohms or greater for six and eight cylinder engines, and 3.0 ohms or greater for four cylinder engines. (Your local auto parts store can do this for you if you not have an ohmmeter)

**Q. What do I do if my coil does not have enough resistance?**

A. You may purchase and install a ballast resistor from your local auto parts store. You may also choose to purchase a Flame-Thrower™ 40,000-volt coil, which provides resistance internally. Note: Many vehicles come with a resistor wire or a ballast resistor. These applications do not need an additional resistor.

**Q. What happens if I leave the ignition switch on when the engine is not running?**  
A. This can cause you coil to overheat, which may cause permanent damage to the coil and the Ignitor™.

**Q. May I modify the length of the Ignitor™ wires?**

A. Yes, you may cut the wires to any length your application may require. You may also add lengths of wire if needed (20-gauge wire). Please make sure all wire splice are clean and connections are secure.

**Q. Will the shift interrupter on an OMC stern drive boat work with the Ignitor™?**  
A. The Ignitor is compatible with all OMC stern drive applications, when equipped with a "diode fix". If you purchased a kit that does not include the "diode fix" diagram, call our tech line.

**Q. How can I get additional help?**

A. Call our tech line (909-599-5955) for any further instructions or questions.

**Q. How can I get additional help?**  
A. Call our tech line (909-599-5955) for any further instructions or questions.

440 E. ARROW HIGHWAY, SAN DIMAS, CA 91773  
www.pertronix.com

## LIMITED WARRANTY


Manufacturer warrants to the original Purchaser of its solid state ignition system (product) that the Ignitor, magnet assembly and wiring (components) shall be free from defects in material and workmanship for a period of (30) months from the first day of use in the Purchaser's industrial truck, stationary, auto or truck engine distributor.  
If within the period of the foregoing warranty manufacturer finds after inspection that the product or any component thereof is defective, manufacturer will, at its option, repair such product or component or replace them with identical or similar parts PROVIDED that within such period Purchaser

## INSTALLATION INSTRUCTIONS FOR PART NUMBERS ML-141, ML-161 & ML-181

- Q. Before installing, please read the following important information...**
1. The Ignitor is designed for **12-volt negative ground** systems.
  2. The Ignitor is compatible only with a "points style" coil. Six & eight cylinder engines require a minimum of **1.5 ohms of resistance**. Four cylinder engines require a minimum of **3.0 ohms of resistance**.
  3. If your ignition system presently is equipped with a **ballast resistor**, **do not remove it** (See Figure 3).
  4. Caution: never use a "HEI" type coil with the Ignitor. This type of coil will damage the module, cause it to fail, and void the warranty.
  5. The **red wire** from the Ignitor must be connected to the **positive** side of the coil, or a 12-volt (+) switched power source. (See Figure 2 & 3). The black wire must be connected to the negative (-) side of the coil.

1. Turn the ignition switch off and disconnect the battery negative (-) cable.
2. Remove the distributor cap and rotor. Do not disconnect the spark plug wires from the cap.
3. Examine the distributor cap and rotor for excessive wear or damage. Replace as needed.
4. Disconnect the points wire from the negative (-) terminal of the ignition coil.
5. Remove the nuts and washers from the point wire stud and remove the stud.
6. Loosen the two horizontal nuts that retain the breaker plate, and remove the assembly. Do not remove the nuts and screws. NOTE: Some Mallory distributors hold the breaker plate assembly in place with two vertical screws. Remove these screws in order to lift out the breaker plate.
7. The Ignitor does not require any modification to the distributor. Therefore the breaker plate, points, condenser and hardware can be used as backup.
8. Line up the slots in the Ignitor plate with the mounting screw heads. The cut out should be near the hole in the distributor housing where the lead stud was located.
9. Press down on the Ignitor plate while tightening the mounting screws and nuts. **NOTE:** If your breaker plate was held in place with vertical screws, use the two countersunk notches on the edge of the Ignitor plate to fasten it. Make sure that the screw heads fit in the notches and are tight.

## The 40,000 volt Flame-Thrower™



Oil filled chrome on steel base. Epoxy version for racing.

## PERTRONIX Inc



## Flame-Thrower™ LOW resistance... HIGH performance spark plug wires



- Maximizes energy and reliability over the full RPM range
- 40,000 available volts
- Enables larger plug gaps for greater power efficiency, more power
- Delivers an average of 15% more spark energy and voltage
- Legal in all 50 States and Canada
- Fits existing brackets
- Made in U.S.A



10. Insert both Ignitor wires through the opening in the distributor housing where the lead stud was located.

11. Pull the grommet into place. **NOTE:** Some distributors have undersized openings. Use a lubricant to ease installation. Be careful not to damage the wires or grommet.

12. Install the magnet sleeve over the shaft and onto the point cam. Turn the sleeve until it lines up with the lobes of the point cam and press down firmly.

13. Install the rotor. **NOTE:** Mallory rotors must be used for proper fit and operation.

14. ML-161 & ML-181 are provided with a rotor spacer ring. Use this piece only if a gap is present between the magnet sleeve and rotor after installation.

15. Remove the excess wire from inside the distributor housing by gently pulling the wire through the grommet. Check to insure that the wire does not interfere with any moving parts.

16. Install the distributor cap. Check to insure that all spark plug wires are seated securely in the distributor cap.

17. Attach the black Ignitor wire to the negative coil terminal.

18. For installations that do not use a primary ballast resistor, connect the red Ignitor wire to the positive coil terminal.

19. Re-connect the battery.

20. Start the engine and allow it to reach normal operating temperature. Check the timing, and adjust to the desired setting.

**ATTENTION O.M.C. BOAT OWNERS....** If your boat is equipped with a shift interrupter you will need to install the following "FIX" to insure proper operation of the unit.

#### O.M.C. SHIFT INTERRUPTER FIX.





FIGURE 1  
WIRING DIAGRAM  
CONVENTIONAL POINTS  
SYSTEM  
WITH BALLAST RESISTOR

FIGURE 2  
WIRING DIAGRAM  
IGNITOR SYSTEM  
WITHOUT BALLAST RESISTOR

FIGURE 3  
WIRING DIAGRAM  
IGNITOR SYSTEM  
WITH BALLAST RESISTOR



NOTE: A RESISTOR WIRE OR BALLAST RESISTOR MAY OR MAY NOT BE INCLUDED IN THE ORIGINAL EQUIPMENT. THEY ARE NOT TO BE CHANGED IN ANY WAY WITH THE INSTALLATION OF AN IGNITOR SYSTEM.